Sensor Faucet Introduction



Application





Appearance








RJY-11-B110AD








Drawing





Technical Pareamters



No.	ltem	Parameters
01	Input	DC 4.5-6.4V 4pcs AA alkaline batteries/AC 110-240V adapter
02	Standby Power Consumption	≦ 33 uA
03	Sensor Distance	 Adjustable range 7-21CM Default distance when power connected 9±10%CM Sensor distance will automatically adjusted in 30s.
04	Sensor Delay	0.36 s
05	Pulse Width	≤20 ms
06	Max Washing Period	60±6s
07	Working Temperature	0 ~ 50 °C
08	Storage Temperature	- 40 ~ 80 ℃
09	Relative Humidity	10 % - 95 %
10	LED Flash	 LED flash 5 times when power connected. Object in the sensor range, LED flash once. Low power indiction voltage 4.5±0.1V, LED continously flash for 10s with 0.5s per time.
11	Sensor Programming	Hands in sensor range, water automatically flow. Hands out of sensor range, water automatically stop.
12	Stability	Sensor distance changes less than ± 10 % if working voltage decreases from DC6.4V to DC4.6V Sensor distance changes less than ± 10 % if temperature increases from 0°C to ± 70 °C.

Technical Pareamters



No.	ltem	Parameters		
13	Anti-inteference	 There's no malfunction if more than one systems working together at the same time with distance of 50cm. AC powered product: Access to 1KW hair dryer and 40W electronic ballast fluorescent lamp in the same power socket. DC powered product: Connect 1KW hairdryer and 40W electronic ballast fluorescent lamp at a distance of 2m Turn on and off the electric appliance for 3 times, without error. Set the light source in the direction of 45 °, so that the illumination reaches 50LX. Sensor distance changes no more than ±10% 		
14	On/off Delay	Turn on ≤ 1 s, Turn off ≤ 1.5 s		
15	Working Pressure	0.05MPa-0.6MPa		
16	Water Flow	Static water pressure 0.1±0.01Mpa, Q=4.5L/Min (Q is water flow and water efficiency levle 2)		
17	Life Span	Dynamic water pressure 0.4±0.02MPa; water flow≥0.1L/s; life span>500,000 circles on/off		
18	Anti-mounting Load	20N*M		
19	High-low Temperature Duability	After stored in the test chamber at 55±2°C for 4H, the sample was stored at room temperature for 2H.The joint will be stored in the -10±3°C test chamber for 4H, then set at room temperature to restore 2H. The sample meets the sealing requirements and water flow change is less than 5%.		
20	Water Hammer Performance	< 0.2Mpa Turn on the product to fill the water pipe with water and waits until to the steady flow rate. The peak pressure of instantaneous turning off the product.		
21	Waterproof	Battery case IP 24 Infrared sensor IP 67 Solenoid valve IP 67		







Function



Low Power Indication

This may indicate it is time to replace existing batteries with new ones or there is not enough power going to unit.





Automatic on/off

1. Infrared sensor faucet automatically turns on and off (Convenience & Hygiene).

2. Time Limit: Washing time is set for 60 seconds.








Sensor Distance Automatically Adjusted Sensor distance automatically adjusted according to working conditions and environment.






Easy Installation Compact design and easy to install.

~ ī.





Battery and Main Power Supply

1. Power supply: DC6V/AC110-240V

2. Compact size

3. The valve will automatically stop water flowing if no power supplied.

Advantage



Anti-electromagnetic Interference

The faucets work as usual even if in strong electro-magnetic interference area.




Made of Refined Brass

Faucets body is made of high quality brass.











Faucets pass 24 hours salt and sp





Low Power Consumption


Four pieces AA alkaline batteries last 24 months with 3,000 circles/month.

LAST 24 MONTHS

М



Installation



Step 1: Fix faucet body to the basin with nuts and gaskets.


- Step 2: Drill two holes in wall and fix control box under the basin.
- Step 3: Connect faucet water hose to the control box.
- Step 4: Connect sensor wire.
- Step 5: Plug adapter to the main power supply.

Important Note


Make sure all the wires are well connected. Make sure the batteries are installed correctly.



图C-1










图C-2






图C-6

图C-5

Battery Replace





*Indicator light will flash continuously if battery power is low, reminding you of replacing batteries. Step 1: Remove the battery case cover. Step 2: Replace with 4 AA alkaline batteries.

*Make sure the batteries are installed correctly (positive and negative charge). *Do NOT mix new old batteries. *Do NOT mix batteries of different brands.

Maintenance



Problem	Possible Reason	Solution
	No main power	Check main power and connect main power
Detect sensor but no LED light flash, no water flow	No batteries OR batteries installed incorrectly	Install batteries and make sure batteries are installed correctly.
	Wires not well connected	Reconnect wires
Sensor with LED flash but no	Object in the sensor range	Remove the object
water flow	Dirt/water on sensor housing	Clean sensor housing
Sensor LED flash continously but no water flow	Batteries run out	Replace with new batteries
Sensor LED flash once when detected but no water flow	Water valve is off	Turn on water valve
	Dirt on valve	Clean valve
Water continously flow	Water pressure is too high	Adjust water pressure between 0.05-0.7MPa
	Main water valve is not fully opened	Fully turn on main water valve
Water flow too small	Dirt on water filter net	Clean filter net
	Water pressure is too low	Adjust water pressure between 0.05-0.7MPa



